



### Notes

1. The boom trailer is to be stored near the boat launch ramp during barge offloading.
2. Initial deployment to be the launch of boom from the boat ramp, around the barge and tow boat
3. The next move will be to tighten the boom as possible to reduce containment area.

